



HARTFORD

INDUSTRIAL CO.,LTD.

---

---

---

Service manual part engine  
For CG-125/150

Issued date:April 1999

# Chapter Contents

Chapter 1 Foreword

Chapter 2 General specifications

Chapter 3 Reason a breakdown

Chapter 4 Cylinder, cylinder head, valves and piston

Chapter 5 Generator /Start motor

Chapter 6 Clutch and gear box

Chapter 7 Carburetor

Chapter 8 Removing and Installing the engine

Chapter 9 Maintenance

Chapter 10 Electrical system

# Chapter 1 Foreword

# Hartford Industrial Co., Ltd.

	1.Foreword	NO	CG
		Page	1-1

Hartford motorcycle engines state of the art power drivingpower , torque , output , smoothness of running , and fuelconsumption are the prime factors in determining the performance of a motorcycle engine .

At Hartford we focus on these critical points , striving to create an engine that offers the maximum in motorcycle driving performance .

At the heart of Hartford is engine production ability is our state of the art production facility , which is set up with Flexible Manufacturing System (FMS) . The FMS is planned and designed by Hartford is engineering staff , and is composed of a series of Hartford machining centers .

Our engine production capabilities do not end with engineering and production . Our commitment to quality is as modern and comprehensive as our facility . The most up to date testing and measurement devices are used to assure that the engines we ship will meet your most exacting standards .

We also maintain a comprehensive spare parts inventory , with items available for immediate delivery . No matter what your type of motorcycle , we have the performance engines to meet your needs at the right price .

Hartford employs a wide variety of sophisticated testing instruments for rigorous testing of the engine performance .

# Chapter 2 General Specifications

2.1 Profile diagram and Main part name -----	2-1
2.1.1 Profile diagram -----	2-1
2.1.2 Main part name-----	2-2
2.2 Engine specifications-----	2-3
2.3 Lubrication system-----	2-4
2.4 Transmission -----	2-5
2.4.1 Clutch-----	2-5
2.4.2 Gear-----	2-5
2.5 Other -----	2-6
2.5.1 Ignition system -----	2-6
2.5.2 Generator -----	2-6
2.5.3 Base-----	2-6
2.5.4 Torque settings -----	2-7
2.5.5 Points for attention -----	2-8
2.5.6 Special tools-----	2-9

# Hartford Industrial Co., Ltd.



## 2. General Specifications

NO



CG

Page

2-1

### 2.1 Profile diagram and Main part name

#### 2.1.1 Profile diagram



# Hartford Industrial Co., Ltd.



## 2. General Specifications

NO

CG


Page

2-2

### 2.1.2 Main part name

**Main part:**

- |                     |                   |                     |
|---------------------|-------------------|---------------------|
| 1. Cylinder         | 2. Cylinder head  | 3. Carburetor       |
| 4. Holder comp pkr  | 5. Valve          | 6. Oil pump         |
| 7. Piston           | 8. Clutch         | 9. Right crank case |
| 10. Left crank case | 11. Generator     | 12. Leak bolt       |
| 13. Drive sprocket  | 14. Engine number | 15. Starter Gear    |



# Hartford Industrial Co., Ltd.

	<h2>2.General Specifications</h2>	NO	CG
		Page	2-3

## 2.2 Engine Specifications

Item	125C.C.(4/5speed)	150C.C.(4/5speed)
Model (CG type)	Air-cooled, single-cylinder OHV four-stroke	Air-cooled, single-cylinder OHV four-stroke
Cylinder layout	Single cylinder canted 15 degrees	Single cylinder canted 15 degrees
Fuel requirement	90 octane or higher	90 octane or higher
Bore and stroke	56.5 x 49.5mm	62 x 49.5mm
Capacity	124cc	149cc
Compression ratio	9:1	9.6:1
Weight (dry / wet)	33kg	34kg
Intake valve timing	5 degrees BTDC / 35 degrees ABDC	16 degrees BTDC 22 degrees ABDC
Exhaust valve timing	30 degrees BBDC / 5 degrees ATDC	30 degrees BBDC / 5 degrees ATDC
Intake valve clearance	0.06-0.08mm	0.06-0.08mm
Exhaust valve clearance	0.06-0.08mm	0.06-0.08mm
Idle speed	1400 ± 100 rpm	1400 ± 100 rpm
Combustion chamber type	Hemispherical	Hemispherical
Valve operation	Single camshaft OHV	Single camshaft OHV
Max.power(ps/rpm)	9.5/8200	12/8300
Max.torque(kg-m/rpm)	0.95/8200	1.2/8300
Fuel economy (km/l)	45 more or less depends on road conditions	45 more or less depends on road conditions

# Hartford Industrial Co., Ltd.



## 2.General Specifications

NO

CG

Page

2-4

### 2.3 Lubrication system

Item	125C.C.(4/5speed)	150C.C.(4/5speed)
Oil pump type	Gerotor	Gerotor
Oil filter type	Centrifugal and screen	Centrifugal and screen
Oil flow rate	4.4l/min @ 8500rpm	4.4l/min @ 8500rpm
Oil grade	SAE 10W/30	SAE 10W/30
Oil capacity	0.8 – 1.2L	0.8 – 1.2L
Oil delivery:		
Crankcase	2.44l/min @ 8500rpm	2.44l/min @ 8500rpm
Cylinder head	1.27l/min @ 8500rpm	1.27l/min @ 8500rpm
Transmission	1.63l/min @ 8500rpm	1.63l/min @ 8500rpm

# Hartford Industrial Co., Ltd.

	<h2>2.General Specifications</h2>	NO	CG
		Page	2-5

## 2.4 Transmission

### 2.4.1 Clutch

Item	125C.C.(4/5speed)	150C.C.(4/5speed)
Clutch type	Wet multiple	Wet multiple
Operation	Left hand	Left hand
Torque rating	7.6kgm	7.6kgm
Number of plates	5	5

### 2.4.2 Gear system

Item	125C.C.(4/5speed)		150C.C.(4/5speed)	
	4 speed	5 speed	4 speed	5 speed
Gearbox type	(1)4 Gearbox(International) (2)4 Gearbox(Circulate) (3)5 Gearbox(International)		(1)4 Gearbox(International) (2)4 Gearbox(Circulate) (3)5 Gearbox(International)	
Operation	Left foot		Left foot	
Gear ratios				
Primary reduction	4.055(73/18)	4.055(73/18)	4.055(73/18)	4.055(73/18)
1 <sup>st</sup> gear	2.769(13/36)	2.4 (15/36)	2.769(13/36)	2.4 (15/36)
2 <sup>nd</sup> gear	1.722(18/31)	1.882(17/32)	1.722(18/31)	1.882(17/32)
3 <sup>rd</sup> gear	1.272(22/28)	1.400(20/28)	1.272(22/28)	1.400(20/28)
4 <sup>th</sup> gear	1.000(25/25)	1.130(23/26)	1.000(25/25)	1.130(23/26)
5 <sup>th</sup> gear		0.960(25/24)		0.960(25/24)
Final education	2.773(15/41)	2.773(15/41)	2.773(15/41)	2.773(15/41)

# Hartford Industrial Co., Ltd.

	2.General Specifications	NO	CG
		Page	2-6

## 2.5 Other

### 2.5.1 Ignition system

Item	125C.C.(4/5 speed)	150C.C.( 4/5 speed)
Type	CDI electronic ignition	CDI electronic ignition
Ignition advance at idle	15deg BTDC @ 1400rpm	15deg BTDC @ 1400rpm
Maximum advance	32~35deg @ 3500rpm	32~35deg @ 3500rpm
Combustion type	Cyclic	Cyclic
Ignition coil type	AS41	AS41
Spark plug type	NGK D7 or DR-8EA	NGK D7 or DR-8EA
Thread	12 x 19	12 x 19
Gap	0.6 ~ 0.7mm	0.6 ~ 0.7mm

### 2.5.2 Generator

Item	125C.C.(4/5 speed)	150C.C.( 4/5 speed)
Type	ACG flywheel	ACG flywheel
Voltage regulator / rectifier	Solid state	Solid state
Maximum output	0.12kw / 5000rpm	0.12kw / 5000rpm

### 2.5.3 Base

Item	125C.C.(4/5 speed)	150C.C.( 4/5 speed)
Starting	Kick and electric	Kick and electric
Battery capacity	12V 6AH	12V 6AH
Fuse rating	15A	15A

# Hartford Industrial Co., Ltd.



## 2.General Specifications

NO

CG


Page

2-7

### 2.5.4 Torque settings

Reference settings	Torque kg-m
5mm UNT BOLT	0.45~0.6
6mm UNT BOLT	0.8~1.2
8mm UNT BOLT	1.8~2.5
10mm UNT BOLT	3.0~4.0
12mm UNT BOLT	5.0~6.0
5mm SCREW	0.35~0.5
6mm SCREW	0.7~1.1
6mm RAISED EDGE SCREW	1.0~1.4
8mm RAISED EDGE SCREW	2.4~3.0
10mm RAISED EDGE SCREW	3.0~4.0

# Hartford Industrial Co., Ltd.

	2.General Specifications	NO	CG
		Page	2-8
<p>2.5.5 Points for attention</p> <ol style="list-style-type: none"><li>1.After disassembling , replace all the washer , oil-ring and clips.</li><li>2.Fasten the nuts by the diagonal way.</li><li>3.Use the specified parts and lubricating oil.</li><li>4.Use the tools by the rules.</li><li>5.Use organic solvent to clean all the parts and smear with lubricating oil on their surface before assembling .</li><li>6.Add suitable grease by the rule.</li><li>7.Check the relative position of mechanism after assembling.</li><li>8.Pay attention to safety when you repair and maintain this machine.</li></ol>			

# Hartford Industrial Co., Ltd.



## 2.General Specifications


NO

CG

Page

2-9

### 2.5.6 Special tools



# Hartford Industrial Co., Ltd.



## 2.General Specifications

NO


CG

Page

2-10



VALVE IN & OUT TOOL  
(PART NO.:60000340)



CRANKCASE ASSEMBLY FRAME  
(PART NO.:60000310)

## Chapter 3 Reason a breakdown

3.1 Engine is difficult or impossible to start	-3-1
3.2 Engine output poor -----	3-2
3.3 Idle or show running poor -----	3-3
3.4 Poor high speed running-----	3-4
3.5 Starter motor inoperable -----	3-5
3.6 Start motor turns constantly -----	3-6
3.7 Engine noisy -----	3-7
3.8 High noxious emissions-----	3-8

# Hartford Industrial Co., Ltd.



## 3.Reason a breakdown


NO

CG

Page

3-1

### 3.1 Engine is difficult or impossible to start



# Hartford Industrial Co., Ltd.



## 3.Reason a breakdown


NO

CG

Page

3-2

### 3.2 Engine output poor



# Hartford Industrial Co., Ltd.



## 3.Reason a breakdown


NO

CG

Page

3-3

### 3.3 Idle or slow running poor



# Hartford Industrial Co., Ltd.



## 3.Reason a breakdown


NO

CG

Page

3-4

### 3.4 Poor high speed running



# Hartford Industrial Co., Ltd.



## 3.Reason a breakdown


NO

CG

Page

3-5

### 3.5 Starter motor inoperable



# Hartford Industrial Co., Ltd.



## 3.Reason a breakdown

NO

CG

Page

3-6

### 3.6 Starter turns constantly

Check

Possible cause

Possible reason


Switch off ignition

Motor still turns

Starter solenoid short circuit

Motor stops

Starter drive gear return faulty



# Hartford Industrial Co., Ltd.



## 3.Reason a breakdown

NO

CG


Page

3-7

### 3.7 Engine noisy

Possible cause	Possible reason
Tapping	<ol style="list-style-type: none"><li>1.Valve adjustment excessively loose</li><li>2.Valve rocker arms worn</li></ol>
Piston slap	<ol style="list-style-type: none"><li>1.Cylinder or piston worn</li><li>2.Combustion chamber carbon deposits excessive</li><li>3.Piston pin or connecting rod worn or damaged</li></ol>
Clutch noisy	<ol style="list-style-type: none"><li>1.Clutch drum drive tabs excessively worn</li></ol>
Starter or transmission noisy	<ol style="list-style-type: none"><li>1.Rear wheel cut drive worn or disintegrated</li><li>2.Primary gears worn</li><li>3.Transmission gears worn</li></ol>

# Hartford Industrial Co., Ltd.

	<h2>3. Reason a breakdown</h2>	NO	CG
		Page	3-8


### 3.8 High noxious emissions

CO level	HC level	Possible cause
High	Normal	<ol style="list-style-type: none"> <li>1. Ignition system faulty                             <ol style="list-style-type: none"> <li>a. Ignition timing incorrect</li> <li>b. Spark plug fouled or gap incorrect</li> <li>c. Voltage regulator faulty</li> <li>d. Ignition coil faulty</li> <li>e. Alternator plate or spark plug cap shorted</li> </ol> </li> <li>2. Exhaust valve worn</li> <li>3. Cylinder worn</li> </ol>
Low	High	<ol style="list-style-type: none"> <li>1. Fuel mixture weak or ignition system faulty</li> <li>2. Vacuum leak                             <ol style="list-style-type: none"> <li>a. pressure pipe</li> <li>b. inlet manifold</li> <li>c. caps</li> </ol> </li> </ol>
High	High	<ol style="list-style-type: none"> <li>1. Air filter blocked</li> <li>2. Carburetor faulty                             <ol style="list-style-type: none"> <li>a. Idle mixture too rich</li> <li>b. Float chamber incorrectly assembled</li> <li>c. Choke operation faulty</li> <li>d. Main jet loose</li> <li>e. Idle speed screw or needle seat worn</li> </ol> </li> </ol>

## Chapter 4 Cylinder, cylinder head, valves and piston

4.1 Reason a breakdown -----	4-1
4.2 Specifications -----	4-2
4.3 Removing cylinder -----	4-3
4.3.1 Removing the cylinder head cover -----	4-3
4.3.2 Removing the cylinder head -----	4-3
4.3.3 Removing the cylinder -----	4-4
4.4 Inspection and overhaul -----	4-5
4.4.1 Check the holder comp pkr -----	4-5
4.4.2 Check the pushrod -----	4-5
4.4.3 Check the Guide pushrod -----	4-5
4.4.4 Check the cylinder -----	4-5
4.4.5 Check the piston -----	4-6
4.4.6 Check the spring valves -----	4-7
4.4.7 Check the cylinder head -----	4-7
4.4.8 Inspect the valves and valve guides -----	4-8
4.4.9 Inspect/overhaul the valve seats -----	4-9
4.5 Installing the cylinder -----	4-10
4.5.1 Installing the cylinder -----	4-10
4.5.2 Installing the piston rings -----	4-11
4.5.3 Installing the cylinder head -----	4-12

# Hartford Industrial Co., Ltd.

	<h2>4. Cylinder, cylinder head, valves and piston</h2>	NO	CG
		Page	4-1
<h3>4.1 Reason a breakdown</h3>			
<h4>Compression pressure low</h4>			
<b>Valves</b> Valve clearance incorrect. Valve bent or burnt. Valve timing incorrect. Valve spring broken.		<b>Cylinder head.</b> Cylinder head gasket damaged and leaking. Cylinder head warped. Compression too high. Combustion chamber carbon deposits excessive	
<b>Piston.</b> Cylinder and piston worn or damaged. excessive.		<b>Other causes</b> Combustion chamber carbon deposits	
<b>Engine noisy</b> Valve clearance incorrect. Valve spring broken. Pushrods and rocker spindles loose. Push rods worn or bent Cam lobes worn Camshaft worn Cylinder or piston worn Excessive carbon deposits		<b>Excessive smoke from exhaust</b> Valves, piston or piston rings worn or damaged Piston rings installed incorrectly Cylinder or piston scored	
<b>Note:</b> The rockers, rocker support and pushrods can be serviced with the engine installed in the chassis. Oil to the valve train passes through the cylinder block into the head. Take care not to block the oil passage. Replace the locating dowels. Put some fresh engine oil into the cylinder head and a smear of grease on the valve cover when installing. During service do not scratch or score the cylinder head			
<b>Torque settings:</b>			
Cylinder head nuts		2.8~3.0kgm	
Cylinder head screws		2.8~3.0kgm	
Cylinder head studs		1.0~1.4kgm	
Rocker support		1.0~1.4kgm	

# Hartford Industrial Co., Ltd.

	<h2>4. Cylinder, cylinder head, valves and piston</h2>	NO	CG
		Page	4-2

### 4.2 Specifications

Part	Item	Specification	Service limit
Rocker arms	Inner diameter	12.000~12.018mm	12.1mm
Rocker spindle	Outer diameter	11.984~11.966mm	12.0mm
Pushrod	Cup radius and length	6.5mm/141.5mm	-----
Outer valve spring	Free length	40.9mm	39.7mm
Inner valve spring	Free length	33.5mm	32.5mm
Outer valve spring	Pressure @ length	15.6kg/35.4mm	-----
Inner valve spring	Pressure @ length	7.1kg/30.7mm	-----
Inlet valve stem	Diameter	5.450~5.465mm	5.42mm
Exhaust valve stem	Diameter	5.430~5.445mm	5.40mm
Inlet valve guide	Inside diameter	5.484~5.488mm	5.50mm
Exhaust valve guide	Inside diameter	5.484~5.488mm	5.50mm
Inlet valve to guide	Clearance	0.010~0.035mm	0.08mm
Exhaust valve to guide	Clearance	0.030~0.035mm	0.10mm
Cylinder(125cc)	Bore	56.500~56.513mm	56.6mm
	Out of round	-----	0.05mm
	Obliqueness	-----	0.05mm
Cylinder (150cc)	Bore	62.000~62.013mm	62.1mm
	Out of round	-----	0.05mm
	Obliqueness	-----	0.05mm
Piston(125cc)	Diameter	56.460~56.480mm	56.360mm
Piston pin hole	Diameter	15.002~15.008mm	15.05mm
Piston pin	Outer diameter	14.993~15.00mm	14.85mm
Piston / bore		0.020~0.050mm	0.11mm
Piston(150cc)	Diameter	61.990~61.970mm	61.890mm
Piston pin hole	Diameter	15.002~15.008mm	15.05mm
Piston pin	Outer diameter	14.993~15.00mm	14.85mm
Piston / bore		0.020~0.050mm	0.11mm
Piston ring to Clearance	1 <sup>st</sup>	0.025~0.055mm	0.13mm
	2 <sup>nd</sup>	0.015~0.045mm	0.12mm
Installed end gap	1 <sup>st</sup>	0.15~0.35mm	0.5mm
	2 <sup>nd</sup>	0.15~0.30mm	0.5mm
	Oil ring	0.20~0.50mm	-----
Piston Thickness	1 <sup>st</sup>	1.160~1.185mm	1.15mm
	2 <sup>nd</sup>	1.175~1.190mm	1.16mm

# Hartford Industrial Co., Ltd.



## 4. Cylinder, cylinder head, valves and piston

NO

CG

Page

4-3

### 4.3 Removing the cylinder

#### 4.3.1 Removing the cylinder head cover


Remove the 6mm x 12mm screws  
Remove three 6mm x 28mm cylinder head screws  
Remove the valve cover and gasket

Note: to preserve seal and prevent oil and / or air leaks, do not damage the cylinder head or valve cover mating faces.




#### 4.3.2 Removing the cylinder head

Rotate the engine and find TDC on the compression stroke  
Remove the three rocker support bolts  
Remove the rocker support  
Remove the pushrods



Remove the four cylinder head bolts  
Remove the pushrod guide plate  
Remove the cylinder head and gasket  
Remove the valve retaining collets  
Remove the three 10 x 20mm cylinder locating dowels



# Hartford Industrial Co., Ltd.



## 4. Cylinder, cylinder head, valves and piston

NO

CG

Page

4-4


### 4.3.3 Removing the cylinder

Removing the cylinder


Note: to prevent distortion or damage to the cylinder or piston, avoid the use of excessive force disassembling

Remove the piston pin clips and piston pin

Remove the piston, do not allow the piston pin or clips fall into the crankcase




Remove the cylinder base gasket  
Remove the four cylinder studs  
Remove the four cylinder locating dowels



Remove and discard the cylinder head gasket  
Remove and discard the cylinder base gasket  
Remove the traces of gasket sealant from the cylinder and head

Note: to preserve seal and prevent oil and / or air leaks, do not damage the cylinder head or valve cover mating faces.



# Hartford Industrial Co., Ltd.



## 4. Cylinder, cylinder head, valves and piston

NO

CG

Page

4-5

### 4.4 Inspection and overhaul

#### 4.4.1 Check the holder comp pkr

Inspect the rocker support and pushrod cups for wear or damage

Check the rocker spindle bore for wear, scuffing or burning

Rocker bore service limit: 12.1mm

#### 4.4.2 Check the pushrod

Check the pushrod ends for wear or damage

Check the pushrods for bending or distortion

If unserviceable, replace

#### 4.4.3 Check the guide pushrod

Check the plate damage or rusting

If the pushrods do not move freely, replace the plate

#### 4.4.4 Check the cylinder

Check the cylinder bore for scoring or burning

Measure the cylinder bore

Use a dial indicator to measure for bore out of round


Service limits

Out of round : 0.050mm

Obliqueness: 0.050mm

Bore diameter(125cc):56.60mm

Bore diameter(150cc):62.1mm



# Hartford Industrial Co., Ltd.



## 4. Cylinder, cylinder head, valves and piston

NO

CG

Page

4-6

### 4.4.5 Check the piston

Measure the piston ring to groove clearance  
Remove the piston rings  
Inspect the piston rings for scoring or damage. Measure the piston pin hole diameter and ovality


Service limit : 15.05mm

Measure the diameter of the piston

Service limit (125cc):56.36mm

(150cc):61.89mm

**Piston pin hole diameter**



Measure the 1<sup>st</sup> piston ring thickness

Service limit: 1.15mm


Measure the 2<sup>nd</sup> piston ring thickness

Service limit: 1.16mm

Insert the piston rings into the bore and measure the ring gap

Piston ring gap service limit: 0.5mm


**Piston ring**



Measure the piston pin outer diameter

Service limit : 14.85mm

**Piston pin**



# Hartford Industrial Co., Ltd.



## 4. Cylinder, cylinder head, valves and piston

NO

CG

Page

4-7


### 4.4.6 Check the spring valve

Measure the free length of the valve springs  
Inspect the piston rings for scoring or damage

Measure the piston pin hole diameter and ovality

Outer spring service limit: 39.7mm

Inner spring service limit: 32.5mm




### 4.4.7 Check the cylinder head

Check the cylinder head for scoring or damage

With a straight-edge and feeler gauges, check the head gasket surface for warping or distortion

Service limit : 0.10mm



# Hartford Industrial Co., Ltd.



## 4. Cylinder, cylinder head, valves and piston

NO

CG

Page

4-8

### 4.4.8 Inspect the valves and valve guides

Inspect the valve stems for scoring, damage or burning.

Check that the valves move freely inside the valve guides.

Measure the diameter of the valve stems Valve guide inside diameter service limit.


Inlet valve service limit: 5.42mm

Inlet valve service limit: 5.40mm

Valve guide inside diameter service limit

Inlet valve: 5.50mm

Exhaust valve: 5.40mm



Before measuring the valve guide diameter, remove carbon deposits


Subtract the stem diameter from the valve guide inside diameter and obtain the clearance

Inlet valve: 0.08mm

Exhaust valve: 0.10mm

If the clearance exceeds the service limit, replace the valve and / or the valve guide

Note: when replacing the valve or guide, the valve seat must be ground



# Hartford Industrial Co., Ltd.



## 4. Cylinder, cylinder head, valves and piston

NO

CG

Page


4-9

### 4.4.9 Inspect / overhaul the valve seats

Remove the carbon deposits from the inlet and exhaust valves.



Place a smear of red ink on the valve contact face and rotate the valve in its seat twice. Observe the width and regularity of the contact patch

Replace with new parts valves that are bent or burnt



If the valve seat is pitted or burnt it must be ground

Use 4 to 5 kg of pressure and a right – left rocking motion to re-finish the valve seat surface. Use oil. First use a 45 degree cutter to face the valve seat, then a 32 degree cutter to face the next  $\frac{1}{4}$  of the total seat width. The 60 degree cutter is used to face the next  $\frac{1}{4}$  of the total seat width. Finally, the 45 degree cutter is used again to finish the lower part of the seat. If the valve seat edge is too high, use a 37.5 degree angle cutter to remove material, and a 45 degree cutter to correct the angle. If the valve seat edge is too low, use a 63.5 ° degree angle cutter to remove material, and a 45 degree cutter to correct the angle. Remove the abrasive residue from grinding to prevent premature wear and encourage good sealing of the valve.



# Hartford Industrial Co., Ltd.



## 4. Cylinder, cylinder head, valves and piston

NO

CG

Page

4-10

### 4.5 Install the cylinder

#### 4.5.1 Install the cylinder

Always install new valve stem seals when replacing the valves

Lubricate the valve stems with oil and replace them

Install the valve springs retainers and collets

Do not over-compress the valve springs with the valve spring compressor

Make sure the retainers and collets are correctly installed or serious engine damage is likely.



Reinstalling the cylinder

Fit a new cylinder base gasket

Reinstall the locating dowels and the four cylinder studs.

Tighten the studs into the crankcase with 1.0~1.4 kg-m of torque

Take care not to drop any debris into the crankcase



# Hartford Industrial Co., Ltd.



## 4. Cylinder, cylinder head, valves and piston

NO

CG

Page

4-11

### 4.5.2 Reinstall the piston rings



Reinstall the piston rings with the gaps spaced at 120 degrees around the piston

Avoid damaging the piston or rings during installation  
 The mark on the piston ring indicates the upper side  
 The rings should move freely in their grooves

Install into cylinder as far as the piston pin boss. Align with the connecting rod and replace the piston pin. Use long nose pliers to reinstall the locating

New circlips should be used  
 The ends of the circlip should not touch when reinstalled  
 Take care not to drop a circlip into the crankcase

Be sure that the piston is at TDC on the compression stroke



# Hartford Industrial Co., Ltd.



## 4. Cylinder, cylinder head, valves and piston

NO

CG

Page

4-12


### 4.5.3 Install cylinder head

Replace the three 10mm x 20mm cylinder head locating dowels.

Replace the cylinder head with a new gasket.

Replace the rocker arms and support assembly.


Replace the four cylinder head nuts  
Tighten to 2.8~3.0kgm torque



Install the pushrods

Install the three bolts

Tighten to 1.0~1.4kgm



# Hartford Industrial Co., Ltd.



## 4. Cylinder, cylinder head, valves and piston

NO

CG

Page

4-13



Smear some grease into the rocker arm and before engaging the pushrods  
Pour a little fresh engine oil into the cylinder head.

Check that the "T" mark on the alternator still aligns with pointer in the alternator case

**Be sure that the piston is at TDC on the compression stroke**

Adjust by loosening the locking screws and rotating the adjusting screw. Retighten and check clearance again  
Valve clearance should be 0.06~0.08mm inlet and exhaust

Reinstall the valve cover with a new rubber O-ring and oil lightly  
Replace the three 6 x 28mm cylinder head screws  
Tighten to 2.8~3.0kg-m torque  
Replace the 6 x 12mm screws and tighten to 1.0~1.4kg-m torque



# Chapter 5 Generator/Start motor

## 5.1 Generator ----- 5-1

5.1.1 Removing the lift crank case ----- 5-1

5.1.2 Removing the generator rotor ----- 5-1

5.1.3 Installing the generator rotor ----- 5-1

5.1.4 Installing the lift crank case ----- 5-1

## 5.2 Start motor ----- 5-2

5.2.1 Removing the start motor ----- 5-2

5.2.2 Removnig the start drive gears ---- 5-2

5.2.3 Installing the start motor ----- 5-2

# Hartford Industrial Co., Ltd.



## 5. Generator/Start motor

NO

CG

Page

5-1

### 5.1 Generator


#### 5.1.1 Removing the lift crank case

Remove the starter gear cover

Remove the gearshift pedal

Remove the alternator cover

The alternator is retained in the cover by four screws which can be removed to disassemble it




#### 5.1.2 Removing the generator rotor

Remove the alternator cover

Remove the alternator retaining bolt

Remove the alternator rotor

Remove the alternator stator coil from the cover



#### 5.1.3 Installing the generator rotor


Inspect the coils for damage from contact with the rotor

Inspect the coils for signs of short circuit or broken wires

Replace the coil with a new part if necessary.

Replace the coil taking care to avoid the coil or its leads touching the rotor.

Replace the rotor and tighten the retaining bolt to 2.6~3.2kgm torque



#### 5.1.4 Installing the lift crank case

Replace the alternator cover with the stator coil installed

Refit the electrical connector block

Replace the electrical wire to the neutral indicator switch

Replace the rear half of the left side engine cover

Replace the gearshift pedal

Replace the starter gear cover

# Hartford Industrial Co., Ltd.



## 5. Generator/Start motor

NO

CG

Page


5-2

### 5.2 Start motor

#### 5.2.1 Removing start motor

Remove the starter motor cable from the terminal

Remove the starter motor retaining screws. Remove the starter motor




#### 5.2.2 Removing the starter drive gears

Remove the starter motor drive gear shaft

Remove the starter reduction gear and shaft

Reassemble is the reverse of disassembly



#### 5.2.3 Installing the starter motor

Reassemble is the reverse of disassembly

Replace the starter motor and tighten the retaining bolts to 0.8~1.2kg-m

# Chapter 6 Clutch/Transmission

6.1 Reason a breakdown -----	6-1
6.1.1 Removing the right crank case cover --	6-2
6.2 Clutch -----	6-3
6.2.1 Removing the clutch -----	6-3
6.2.2 Check the clutch -----	6-4
6.3 Transmission -----	6-5
6.3.1 Removing the gearshift mechanism -	6-5
6.3.2 Installing the right crank case cover ----	6-7

# Hartford Industrial Co., Ltd.



## 6. Clutch/Transmission

NO

CG

Page

6-1

### 6.1 Reason a breakdown

If the clutch operation is faulty, first attempt to cure the condition by adjusting the clutch cable.

#### A) Clutch slips under acceleration

1. No slack in the clutch cable
2. Clutch plates worn
3. Clutch springs weak

#### B) Clutch fails to release (vehicle creeps in gear)

1. Too much slack in clutch cable
2. Distorted clutch parts

#### C) Clutch lever loose

1. Clutch cable
2. Clutch operating mechanism worn or damaged

#### D) Difficulty changing gear

1. Gearshift plate distorted
2. Clutch cable adjustment incorrect

#### E) Gearshift pedal detent poor



1. Gearshift return spring broken or displaced
2. Gearshift shaft distorted

#### F) Transmission jumps out of gear

1. Gearshift cam detent spring broken

#### G) Low oil pressure

1. Oil pump gears worn
2. Oil pump faulty



# Hartford Industrial Co., Ltd.



## 6.Clutch/Transmission

NO

CG

Page

6-2

### Special tools

Four-leg socket wrench

Air impact wrench

### Tightening torque

Clutch cover screws:0.8~1.2 kg/m

Oil filter cover screws:4.0~5.0 kg/m

Item	New specification	Service limit
Clutch operating arm free slack	10~20mm	
Clutch spring free length	35.5mm	32.4mm
Clutch friction plate thickness	3.0mm	2.5mm
Clutch plate distortion	0.2mm	
Oil pump inner rotor clearance	0.30mm	0.35mm
Outer rotor to body clearance	0.30~0.36mm	0.40mm
Oil pump cover plate clearance	0~0.06mm	0.11mm

### 6.1.1 Removing the right crank case cover


Remove the exhaust

Remove the footrests

Remove the clutch cable

Remove the kickstarter

Remove the right crank case cover



# Hartford Industrial Co., Ltd.



## 6. Clutch/Transmission

NO

CG

Page

6-3

### 6.2 Clutch

#### 6.2.1 Removing the clutch

Remove the clutch pushrod.

Remove the centrifugal oil filter body.

Use the four-leg socket wrench and air impact wrench to remove the 16 mm retaining nut.

Remove the oil filter body.

Remove the oil seal and clutch pushrod.

Remove the clutch center 20mm C clip.

Remove the clutch spring pressure plate screws.

Remove the clutch spring pressure plate and springs.




Remove the clutch center.

Remove the clutch friction plates.

Remove the clutch plates and pressure plate.

Remove the 20mm retaining ring washer.

Remove the clutch basket.



# Hartford Industrial Co., Ltd.



## 6. Clutch/Transmission


NO

CG

Page

6-4

### 6.2.2 Check the clutch



- Inspecting the friction plates

Measure the thickness of the friction plates and inspect for wear, scoring or damage.

Replace as complete set if necessary

Service limit: 2.5mm

- Inspecting the clutch basket

Remove the 20mm washer and the clutch basket.

Check the faces of the drive slots for indentation

- Inspecting the clutch springs

Measure the free length of the four clutch springs

Service limit: 32.4mm

- Inspecting the clutch plates

Measure the distortion of the plates with a feeler gauge and a flat surface

Service limit: 0.2mm

- Replacing the clutch

Reassembly is the reverse of disassembly

When replacing the clutch springs, tighten the four spring pressure plate screws evenly in sequence tighten to 4.0~5.0kg-m<sup>2</sup>



## 6. Clutch/Transmission

NO

CG

Page

6-5


### 6.3 Transmission

#### 6.3.1 Removing the gearshift mechanism

Remove the gearshift mechanism



Remove the clutch

Remove the gearshift pedal



Remove the gearshift shaft

Note: when removing the gearshift shaft, note the gearshift shaft return spring hooked on the lug located on the crankcase



**Gear shift spindle comp**

# Hartford Industrial Co., Ltd.



## 6.Clutch/Transmission

NO

CG


Page

6-6

Remove the gearshift detent arm

Remove the gearshift cam

Check all parts for wear or damage



Reassembling the gearshift mechanism

Locate the rollers and install the gearshift cam



Reinstall the gearshift shaft and plate



# Hartford Industrial Co., Ltd.



## 6. Clutch/Transmission

NO


CG

Page

6-7

Installing the gearshift shaft

Install the gearshift pedal and check the smooth operation of the gearshift mechanism




Replace the clutch

Replace the oil pump

Replace the clutch cover locating dowels and gasket

Note: the gearshift shaft return spring should locate against the lug in the crankcase



### 6.3.2 Installing the clutch cover


Install the clutch cover

Install the clutch cable

Install the kickstarter and exhaust pipe

Refill the engine with fresh oil

Adjust the clutch cable free slack



# Chapter 7 Carburetor

7.1 Reason a breakdown -----	7-1
7.2 Carburetor -----	7-2
7.2.1 Names of carburetor parts -----	7-2
7.2.2 Removing the carburetor -----	7-2
7.2.3 Throttle valve -----	7-3
7.2.4 Removing the float and float needle --	7-3
7.2.5 Installing the float and float needle ----	7-4
7.2.6 Replace the throttle slide -----	7-4
7.2.7 Inspecting the float needle -----	7-5
7.2.8 Adjusting the float height-----	7-5

# Hartford Industrial Co., Ltd.



## 7. Carburetor

NO

CG

Page

7-1

### 7.1 Reason a breakdown

Engine fires but doesn't run.

No fuel in the fuel tank.

Fuel not reaching the carburetor.

Fuel mixture excessively rich.

No spark at spark plug (ignition system faulty).

Air-filter blocked.

#### Poor idling

Idle speed incorrect

Ignition system faulty

Low cylinder compression

Fuel / air mixture excessively rich

Fuel / air mixture excessively lean

Air-filter blocked

Fuel dirty or contaminated

#### Fuel/air mixture excessively lean.

Carburetor jets blocked.

Carburetor body air passages blocked.

Fuel pipe blocked.

Float level too low

Fuel filter blocked

Float needle faulty or damaged

#### Fuel/air mixture excessively rich

Choke valve seized

Float level too high

Float needle faulty or damaged

#### Remedy

Clean the carburetor and restore normal combustion

Adjust the float level

# Hartford Industrial Co., Ltd.



## 7. Carburetor

NO

CG

Page

7-2

### 7.2 Carburetor

#### 7.2.1 Names of carburetor parts

Throttle valve

Air control lever

Oil cup


Float

Needle

Spring

Carburetor top

Float bowl screws



#### 7.2.2 Removing the carburetor

Turn the fuel valve to the "OFF" position  
Remove the fuel line

Drain the fuel from the carburetor


Note: Fuel is flammable and should be washed off the vehicle if spilled

Remove the air filter hose clamp

Remove the throttle cable

Remove the carburetor mounting nut

Remove the carburetor



# Hartford Industrial Co., Ltd.



## 7. Carburetor

NO


CG

Page

7-3

### 7.2.3 Throttle valve


Remove the needle lock spring  
Remove needle, needle lock clip  
Examine needle and throttle valve  
for wear or damage



### 7.2.4 Removing the float and float needle


Remove the three M4 x 16mm screws  
Remove the float bowl

Return the fuel inside to fuel tank



Remove the support pin with long  
nose pliers

Remove the float and Float needle



# Hartford Industrial Co., Ltd.



## 7. Carburetor

NO

CG

Page

7-4


Remove the jets, float needle and needle valve seat.

Note: Do not damage the jets

Remove the idle mixture screw

Note: Before removing the idle mixture screw. Screw the adjuster screw in. Fully counting the turns

The standard position for the idle screws two turns back from fully screwed in.




### 7.2.5 Installing the float and float needle

Inspect all parts for wear or damage and replace as necessary.

Note: Take care during reassemble not to damage any of the parts.

Reassemble the float needle and needle seat.

Install the jets and idle mixture screws.  
Replace the float bowl




### 7.2.6 Replace the throttle slide

Replace the needle, Needle lock clip and needle lock spring  
Replace throttle cable

Replace the missing chamber cap and the air filter connecting hose.

Check the free closing of the throttle at all handlebar positions.



# Hartford Industrial Co., Ltd.



## 7. Carburetor

NO

CG


Page

7-5

### 7.2.7 Inspecting the float needle

Examine the float and float needle for wear or damage

**Abrade**




### 7.2.8 Adjusting the float height

The float height is set by bending the float tang

Use the special gauge to measure the float height

Correct float height----- 125C.C:14.5mm(Model PD026A)  
150C.C:14mm (Model PD19D)



# Chapter 8

## Removing and installing the engine

8.1 Removing and installing the engine --- 8-1

8.1.1 Removing the engine ----- 8-1

8.1.2 Installing the engine ----- 8-3

# Hartford Industrial Co., Ltd.



## 8. Removing and installing the engine

NO

CG

Page


8-1

### 8.1 Removing and installing the engine

#### 8.1.1 Removing the engine

Drain the engine oil

Turn the fuel valve to the "OFF" position.




Remove the cover left rear crank case and pedal gear change.

Remove the generator wires

Remove the control cables and retaining nuts.


Remove the tachometer cable



Loosen the rear wheel axle

Loosen the chain adjusters and slide the rear wheel forward

Remove the master link and release the drive chain



# Hartford Industrial Co., Ltd.



## 8. Removing and installing the engine

NO


CG

Page

8-2


Removing the spark plug cap

Removing the spark plug




Removing the carburetor mounting nuts and dismount the carburetor.

Remove the crankcase exhaust hose.



Removing the clutch cable

Removing the kick starter



# Hartford Industrial Co., Ltd.



## 8. Removing and installing the engine

NO

CG

Page

8-3

Removing the exhaust pipe nuts  
Removing the exhaust pipe  
Removing the bar comp step

Removing the front engine mounting plate

Note: Before removal, support the front of the engine with a suitable stand or block of wood



Removing the starting motor cable  
Remove the rear engine mounting 8mm bolts.  
Remove the above engine mounting bolts.  
Remove the engine  
Remove the tachometer

Note: when removing the engine take care to avoid damaging any cables or wires

### 8.1.2 Installing the engine

Installation is reverse of disassembly  
Note:

- Take care to correctly reinstall the control cables and electrical wires
- Adjust the throttle cable slack
- Adjust the clutch cable slack
- Refill the engine with the approved oil (SAE10W - 30)



# Chapter 9 Maintenance

9.1 Engine oil/Oil filter-----	9-1
9.1.1 Check the engine oil -----	9-1
9.1.2 Change the engine oil-----	9-1
9.1.3 Clean the oil filter room -----	9-3
9.1.4 Clean the oil filter screen -----	9-3
9.1.5 Check the spark plug-----	9-3
9.2 Periodic maintenance and check-----	9-4

# Hartford Industrial Co., Ltd.



## 9. Maintenance

NO

CG

Page


9-1

### 9.1 Engine oil/Oil filter

#### 9.1.1 Check the engine oil

1. Place the motorcycle on the main stand.
2. Remove the dipstick and wipe it clean with cloth.
3. Insert the dipstick back into the engine.
4. Remove the dipstick once more and observe the level.
5. Add oil as necessary to replenish to the mark.
6. Do not over-fill as this may damage the engine.
7. Check the level again after filling.

### Engine Oil Ruler



Insufficient    Just    Too Much


#### 9.1.2 Change the Engine oil

Note: Before changing the oil, run the engine for 5 minutes to bring it operating temperature

Remove the drain plug and release the engine oil

Check the condition of the drain plug seal

Refill with 0.8 ~ 1.0 liters of oil  
Recommended oil: SAE10W-30



# Hartford Industrial Co., Ltd.




## 9.Maintenance

NO

CG

Page

9-2



Engine oil to suit thermometer

Recommended oil for use:

Use APISG rated oil or a premium grade engine oil.

Recommended oil viscosity

1. In normal climates use SAE 10W-30 or premium grade.
2. In colder weather use SAE 5W-30.
3. The engine oil should be changed after covering the first 300km.
4. The engine oil should then be changed every 1000km.

# Hartford Industrial Co., Ltd.



## 9. Maintenance

NO

CG

Page

9-3

### 9.1.3 Clean the oil filter room

- Remove the exhaust pipe
- Remove the footrests
- Remove the clutch cable
- Remove the kickstarter
- Remove the clutch cover
- Remove the oil filter cover
- Clean as necessary
- Clean the oil filter screen



### 9.1.4 Clean the oil filter screen

- Remove the oil filter cover and screen
- Clean with compressed air


### 9.1.5 Check the spark plug

1. Fouling or excessive gap(A) will cause incomplete combustion.
2. Use a wire brush to clean deposits from the electrodes.
3. Replace spark plugs at 3000~5000km intervals.

- SPARK PLUG TYPE(NGK):

TYPE	D-7EA	D-8EA	DR-8EA
A	0.6~0.7mm	0.6~0.7mm	0.6~0.7mm

Electrode



# Hartford Industrial Co., Ltd.

	<h2>9.Maintenance</h2>	NO	CG
		Page	9-4

## 9.2 Periodic maintenance and check

I:Inspect      A:Adjust      C:Clean      R:Replace      T:Tighten

Inspection period Item to inspect /replace	After the first 300km and every 1000km	Every month 1000~1500km	Every 3000km	Every 6000km
Engine oil	R	R		
transmission oil	R		R	
Clutch	I/A		I/A	
Valve clearances	A		A	
Ignition timing	A		A	
Carburetor			A/C	
Clean oil filter	C		C	
Main screw	I/T		I/T	
Spark plug				R

\*COVERAGE PROVIDED BY THE WARRANTY:

BEFORE 1000km OF NEW MOTORCYCLE HAVE RIDED, PLEASE KEEP SPEED LOWER THAN 60km/hr , IF SPEED IS HIGHER THAN LIMIT , THE ENGINE BREAKS WOULD NOT PROVIDED BY THE WARRANTY .

# Chapter 10 Electrical system

10.1 CDI -----	10-1
10.2 Starter switch assy-----	10-2
10.3 Regulator-----	10-3
10.4 Coil comp -----	10-4
10.5 Electrical assembly draw-----	10-5



### 10.1 CDI

#### CDI(Capacitor Discharge Ignition):

The design of engine on per RPM needs to match the angle ignition that can make engine to own the ideal operation , The main job of CDI is . to provide convenience from the storage of source coil . In fact , the ignition Coil occurs the second side high Voltage to let Pulg . onto ignite , therefore , the gas is ignited .

Figure 1: Ext(Source Coil) provides energy by capacitor 2.2u/400v.

PU(pickup coil) produces a signal to provide CDI to calculate when the action of trigger will be happened . Also , it stores energy on capacitor then it will be sent from point of IGN to ignition coil.

Figure 2: Ignition Flow chat

The calculation of CDI is to do the Flow Chart to.find out where the angle of Ignition





FIGURE 2




FIGURE 1

# Hartford Industrial Co., Ltd.



## 10. Electrical system

NO

CG

Page

10-2

### 10.2 Start switch assy

**SPECIFICATION:**

NOMINAL VOLTAGE: DC12V

NOMINAL CURRENT: 150A

ENERGIZATION CURRENT: equal or below 3V

OPERATING VOLTAGE: equal or below 7.5V

RETURN VOLTAGE: equal or below 3V

INSULATION RESISTANCE: more or equal 1M Ω

RESISTANCE VALUE: 3.4 Ω ± 10% in 20 ° c


**OPERATION DURABILITY:**

8V/150A.5sec ON / 20sec OFF.

reciprocation 1000 times

**VOLTAGE DROPT CONTACT POINT:**

equal or below 0.2V



# Hartford Industrial Co., Ltd.



## 10. Electrical system

NO

CG

Page

10-3

### 10.3 Regulator

REG RELT COMP : As a result magnetor Armature Coil generates Voltage . to AC signal . Thus , it must pass through regulator to change DC signal . To examine the Voltage of Battery by controlling circuit to know whether it needs to send power for Battery Charge . The main job of regulator is to regulate and to provide adequate Voltage for the battery charge and the usage of load .





Figure 1 : Armature Coil in regulator produces AC signal Y (yellow line) P (pink line) to input to D1, D2, D3, D4 it will change AC signal to DC signal and control circuit . The purpose to examine R (red line) (which looks battery and load is to find out how much energy should be . SCR(S1, S2) can drain the left energy .

Figure 1



# Hartford Industrial Co., Ltd.



## 10. Electrical system


NO

CG

Page

10-4

### 10.4 Coil comp



#### ANTI-RADIO INTERFERENCE SYSTEM

STATIC RESISTANCE:  $R1: 0.31 \pm 0.03 \Omega$ ,  $R2: 4.0 \pm 0.4 \Omega$

LOWEST RPM. FOR CONTINUOUS IGNITION:

equal or below 300rpm /6mm

CONTINUOUS IGNITION RPM. RANGE:

equal or below 300~1000rpm /6mm

DIELECTRIC RESISTANCE: over 1000M  $\Omega$

HIGH TEMP TEST:

80 ° Constant Temperature. over 1 hour. NO change.

NOTE:

ANTI-RADIO INTERFERENCE SYSTEM: 125C.C. UP 10  $\Omega$ ,  
100C.C. DOWN 5  $\Omega$

# Hartford Industrial Co., Ltd.



## 10. Electrical system

NO

CG

Page

10-5

### 10.5 Electrical assembly draw

